BLUEBOX RFid System

Table part 1: order code, description, length, DESKTOP and BASIC

order CODE	DESCRIPTION	LENGHT (Meter)	DESKTOP			BASIC							
			LF	HF	UHF	LF		HF		UHF			
			R-IN-LF-3122L[3]	R-IN-HF-3122H[3]	R-IN-UHF-3122U[3]	R-IN-LF-5121L	R-IN-LF-5131L	R-IN-HF-5121H	R-IN-HF-5131H	R-IN-UHF-5121U	R-IN-UHF-5131U	R-IN-UHF-LR-4A-232	R-IN-UHF-LR-4A-ET
POWER													
CABLES													
0901A	Power cable with M12-A 5PIN (female) connector and open ends	3	-	-	-	-	-	-	-	-	-	-	-
0919A	Power cable with M12-A 4PIN (female) connector and open ends	2	-	-	-	-	-	-	-	-	-	-	-
0922A	M12-A 5PIN (female) connector with open ends for power and DB9 for RS232/485	3	-	-	-	-	-	-	-	-	-	-	-
CONNECTOR													
0910A	M12-A 5PIN (female) connector only with screw connections - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
0918A	M12-A 5PIN (female) connector only with screw connections - PLASTIC SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
0930A	M12-A 4PIN (female) connector only with screw connections - PLASTIC SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES													
RS232/485													
0903A	RS232/485 cable with M12-A 8PIN (female) with DB9 for RS232 and open ends for RS485	3	-	-	-	-	-	-	-	-	-	-	-
0904A	RS232/485 cable with M12-A 8PIN (female) and open ends	3	-	-	-	-	-	-	-	-	-	-	-
0914A	M12-A 8PIN (female) connector only with screw connections for RS232/485 - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
ETH													
0902A	ETH cable with M12-D (male) and RJ45, DYNAMIC installation	3	-	-	-	-	-	-	-	-	-	-	-
0913A	M12-D 4PIN (male) connector only with screw connections for Ethernet - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
0916A	M12-D 4PIN (male) connector only with screw connections for Ethernet - Plastic SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
0921A	ETH cable with M12-D (male) and RJ45, FIXED installation	20	-	-	-	-	-	-	-	-	-	-	-
PROFIBUS													
0906A	Profibus termination resistance with M12-B 4 PIN (male)	-	-	-	-	-	-	-	-	-	-	-	-
0907A	Profibus "T" connector with 3 M12-B 4PIN (1 Male - 2 Female)	-	-	-	-	-	-	-	-	-	-	-	-
0908A	PROFIBUS cable with M12-B (male) and M12-B (female)	3	-	-	-	-	-	-	-	-	-	-	-
0912A	M12-B 4PIN (male) connector only with screw connections for profibus - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
I/O													
0905A	I/O cable with M12-A 5PIN (male) and open ends	3	-	-	-	-	-	-	-	-	-	-	-
0911A	M12-A 5PIN (male) connector only with screw connections for advant I/O - METAL SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
0917A	M12-A 5PIN (male) connector only with screw connections - PLASTIC SHELL -	-	-	-	-	-	-	-	-	-	-	-	-
0920A	I/O cable with M12-A 12PIN (male)	4	-	-	-	-	-	-	-	-	-	-	-
0931A	M12-A 12PIN (male) connector only with solder connections - PLASTIC SHELL -		-	-	-	-	-	-	-	-	-	-	-
USB													
0909A	USB interface with M12-USB-MINI and USB A connector	1	-	-	-	-	-	-	-	-	-	-	-
0928A	USB cable A (male) - B (male)	1,8	X	X	X	-	-	-	-	-	-	-	-
0929A	USB mini cable A (male) - B 5p MINI usb	1,5	-	-	-	-	-	-	-	-	-	-	-
TTL / Mag.Stripe Emulation													
0905A	Cable with M12-A 5PIN (male) and open ends	3	-	-	-	-	-	-	-	-	-	-	-
CAPS													
0915A	Plastic cap for M12 female connectors	-	-	-	-	-	-	-	-	-	-	-	-
0923A	TNC cap for female connectors	-	-	-	-	-	-	-	-	-	X	-	-
0924A	Cable housing IP67 for ETH connections with RJ45	-	-	-	-	-	-	-	-	-	-	-	-
0925A	Plastic cap IP67 for RJF544 connector	-	-	-	-	-	-	-	-	-	-	-	-
0926A	Platic cap for M12 usb connector	-	-	-	-	-	-	-	-	-	-	-	-
ADAPTERS													
9951U	TNC (female) – TNC (female) adapter	-	-	-	-	-	-	-	-	-	-	-	-
9952U	TNC (male) 50 Ohm terminator	-	-	-	-	-	-	-	-	-	-	-	-
9953U	TNC (female) – N (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
9954U	TNC (male) – SMA (female) adapter	-	-	-	-	-	-	-	-	-	-	-	-
9955U	TNC (female) - TNC (male) right angle adapter	-	-	-	-	-	-	-	-	-	X	-	-
9957U	SMA (male) - SMA (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
9958U	Panel TNC (female) - ufl (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
9959U	TNC (female) – SMA (male) adapter	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS													
9903U	Antenna cable withTNC (male) and TNC (male)	3	-	-	-	-	-	-	-	-	X	-	-
9904U	Antenna cable withTNC (male) and TNC (male)	6	-	-	-	-	-	-	-	-	X	-	-
9906U	Antenna cable withTNC (male) and TNC (male)	10	-	-	-	-	-	-	-	-	X	-	-
9907U	Antenna cable withTNC (male) and TNC (male)	15	-	-	-	-	-	-	-	-	X	-	-
9908U	Antenna cable withTNC (male) and TNC (male)	25	-	-	-	-	-	-	-	-	X	-	-
POWER SUPPLY													
0951A	Power Supply AC - DC 15W 5 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
0958A	Power Supply AC - DC 15W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
0959A	Power Supply AC - DC 35W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
0960A	Power Supply AC - DC 50W 12 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
0965A	Power Supply AC - DC 35W 15 Vdc OUT	-	-	-	-	-	-	-	-	-	-	-	-
0971A	Power Supply AC - DC 35W 24 Vdc OUT	-	-	-	-	X	X	X	X	X	X	-	-
0972A	Power Supply AC - DC 50W 24 Vdc OUT	-	-	-	-	X	X	X	X	X	X	-	-
0990A	Power Supply 24V 35W with box BB	-	-	-	-	X	X	X	X	X	X	-	-
0991A	Power Supply 24V 25W with M12-A-5PIN (female) Wall mount adaptor - European 2P	1,8	-	-	-	-	-	-	-	-	-	-	-
SUPPORTS													
9921U	Mounting kit for Antennas 9126U & 9127U	-	-	-	-	-	-	-	-	-	-	-	-
9922U	Munting kit for Antennas 9128U & 9129U	-	-	-	-	-	-	-	-	-	-	-	-
9923U	Foldind stand for Antennas 9126U & 9127U	-	-	-	-	-	-	-	-	-	-	-	-
9924U	Adjustable stand for CX-E / CX-EL readers	-	-	-	-	-	-	-	-	-	-	-	-
9925U	Adapter 9924U/9126U	-	-	-	-	-	-	-	-	-	-	-	-
9926U	Adjustable stand for CX-E / CX-EL readers / 9126U	-	-	-	-	-	-	-	-	-	-	-	-

Table part 2: ADVANT

order CODE	ADVANT																													
	LF									HF									HF MR			UHF								
	R-IN-LF-5221L	R-IN-LF-5222L	R-IN-LF-5223L	R-IN-LF-5231L	R-IN-LF-5232L	R-IN-LF-5233L	R-IN-LF-5241L	R-IN-LF-5242L	R-IN-LF-5243L	R-IN-HF-5221H	R-IN-HF-5222H	R-IN-HF-5223H	R-IN-HF-5231H	R-IN-HF-5232H	R-IN-HF-5233H	R-IN-HF-5241H	R-IN-HF-5242H	R-IN-HF-5243H	R-IN-HF-5231HM	R-IN-HF-5232HM	R-IN-HF-5233HM	R-IN-HF-5231HM	R-IN-HF-5232HM	R-IN-HF-5233HM	R-IN-HF-5231HM	R-IN-HF-5232HM	R-IN-HF-5233HM	R-IN-HF-5231HM	R-IN-HF-5232HM	R-IN-HF-5233HM
POWER																														
CABLES																														
0901A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0919A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0922A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CONNECTOR																														
0910A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0918A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0930A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES																														
RS232/485																														
0903A	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-
0904A	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-
0914A	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-
ETH																														
0902A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
0913A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
0916A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
0921A	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-
PROFIBUS																														
0906A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
0907A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
0908A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
0912A	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X	-	-	X
I/O																														
0905A	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-
0911A	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-
0917A	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-	X	X	-
0920A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0931A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
USB																														
0909A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0928A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0929A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
TTL / Mag.Stripe Emulation																														
0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CAPS																														
0915A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0923A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
0924A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0925A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0926A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
ADAPTERS																														
9951U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9952U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	-	-	-
9953U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9954U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9955U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
9957U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9958U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9959U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS																														
9903U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
9904U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
9906U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
9907U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
9908U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
POWER SUPPLY																														
0951A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0958A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0959A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0960A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0965A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0971A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0972A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0990A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0991A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
SUPPORTS																														
9921U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9922U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9923U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9924U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9925U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9926U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Table part 3: M30 reader and CX

order CODE	M30 reader								CX											
	LF		HF		UHF				eth with RJ45						eth with M12					
	R-IN-LF-5224L	R-IN-LF-5225L	R-IN-HF-5224H	R-IN-HF-5225H	R-IN-UHF-5224U	R-IN-UHF-5225U	R-IN-UHF-5226U	R-IN-UHF-5227U	R-IN-UHF-5325U	R-IN-UHF-5325U-RTC	R-IN-UHF-5335U	R-IN-UHF-5335U-RTC	R-IN-UHF-5345U	R-IN-UHF-5345U-RTC	R-IN-UHF-5326U	R-IN-UHF-5326U-RTC	R-IN-UHF-5336U	R-IN-UHF-5336U-RTC	R-IN-UHF-5346U	R-IN-UHF-5346U-RTC
POWER																				
CABLES																				
0901A	-	-	-	-	-	-	Y	Y	X	X	X	X	X	X	X	X	X	X	X	X
0919A	X	X	X	X	X	X	Y	Y	-	-	-	-	-	-	-	-	-	-	-	-
0922A	X	X	X	X	X	X	-	-	X	X	X	X	X	X	X	X	X	X	X	X
CONNECTOR																				
0910A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0918A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0930A	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES																				
RS232/485																				
0903A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0904A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0914A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ETH																				
0902A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
0913A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
0916A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
0921A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X
PROFIBUS																				
0906A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0907A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0908A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0912A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
I/O																				
0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0911A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0917A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0920A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
0931A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
USB																				
0909A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0928A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
0929A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
TTL / Mag.Stripe Emulation																				
0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CAPS																				
0915A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
0923A	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
0924A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	-	-	-	-	-	-
0925A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	-	-	-	-	-	-
0926A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ADAPTERS																				
9951U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9952U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	X	X
9953U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9954U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9955U	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
9957U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9958U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9959U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS																				
9903U	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
9904U	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
9906U	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
9907U	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
9908U	-	-	-	-	-	-	-	-	-	-	X	X	X	X	-	-	X	X	X	X
POWER SUPPLY																				
0951A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0958A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0959A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
0960A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
0965A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
0971A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0972A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0990A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
0991A	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	X	X	X
SUPPORTS																				
9921U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9922U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9923U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9924U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9925U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9926U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Table part 4: CX-E, CX-EL and ANTENNA

order CODE	CX-E						CX-EL						ANTENNA														
	ETSI			FCC			ETSI			FCC			SMA							TNC						N	
	R-IN-UHF-5426U-G	R-IN-UHF-5426U-RTC-G	R-IN-UHF-5427U-G	R-IN-UHF-5426U-G-FCC	R-IN-UHF-5426U-RTC-G-FCC	R-IN-UHF-5427U-G-FCC	R-IN-UHF-5526U-G	R-IN-UHF-5526U-RTC-G	R-IN-UHF-5527U-G	R-IN-UHF-5526U-G-FCC	R-IN-UHF-5526U-RTC-G-FCC	R-IN-UHF-5527U-G-FCC	R-IN-UHF-9021U	R-IN-UHF-9022U	R-IN-UHF-9121U	R-IN-UHF-9122U	R-IN-UHF-9123U	R-IN-UHF-9124U	R-IN-UHF-9125U	R-IN-UHF-9126U	R-IN-UHF-9127U	R-IN-UHF-9131U	R-IN-UHF-9132U	R-IN-UHF-9133U	R-IN-UHF-9134U	R-IN-UHF-9128U	R-IN-UHF-9129U
POWER																											
CABLES																											
0901A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0919A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0922A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CONNECTOR																											
0910A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0918A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0930A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
INTERFACE CABLES																											
RS232/485																											
0903A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0904A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0914A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ETH																											
0902A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0913A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0916A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0921A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
PROFIBUS																											
0906A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0907A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0908A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0912A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
I/O																											
0905A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0911A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0917A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0920A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0931A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
USB																											
0909A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0928A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0929A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
TTL / Mag.Stripe Emulation																											
0905A	-	-	X	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CAPS																											
0915A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0923A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0924A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0925A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0926A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
ADAPTERS																											
9951U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9952U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9953U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X
9954U	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-
9955U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	X	X	X	X	X	X	X	-	-
9957U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9958U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
9959U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
CABLE EXTENSIONS																											
9903U	-	-	-	-	-	-	-	-	-	-	-	-	X[1]	X[1]	X	X	X	X	X	X	X	X	X	X	X	X[2]	X[2]
9904U	-	-	-	-	-	-	-	-	-	-	-	-	X[1]	X[1]	X	X	X	X	X	X	X	X	X	X	X	X[2]	X[2]
9906U	-	-	-	-	-	-	-	-	-	-	-	-	X[1]	X[1]	X	X	X	X	X	X	X	X	X	X	X	X[2]	X[2]
9907U	-	-	-	-	-	-	-	-	-	-	-	-	X[1]	X[1]	X	X	X	X	X	X	X	X	X	X	X	X[2]	X[2]
9908U	-	-	-	-	-	-	-	-	-	-	-	-	X[1]	X[1]	X	X	X	X	X	X	X	X	X	X	X	X[2]	X[2]
POWER SUPPLY																											
0951A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0958A	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0959A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0960A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0965A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0971A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0972A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0990A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
0991A	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
SUPPORTS																											
9921U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-
9922U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X
9923U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-
9924U	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	X[4]	X[4]	-	-	-	-	-	-
9925U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-
9926U	X	X	X	X	X	X	X	X	X	X	X	X	-	-	-	-	-	-	-	X	X	-	-	-	-	-	-

X[1] with the addition of 9954U
X[2] with the addition of 9953U
X[3] USB cable included
X[4] with the addition of 9925U
Y wire colours not according to CAN-Bus standard